

Beredskabsplan på Foulum Biogasanlæg

BRAND

1. Stands ulykken

Typen af slukningsmateriel ses på nødplanen til venstre.

2. Alarmere

Kontakt en af følgende driftspersonale:

Driftsleder: Mogens Møller
Mobil: 20 76 27 32 eller 86 68 04 30

Driftstekniker: Allan Jensen
Mobil: 20 80 19 97

Driftstekniker: Peter Nielsen
Mobil: 41 12 29 46

Afklar med en af ovenstående driftspersonale om branden kræver alarmering af myndighederne.

Alarm
Tlf.: 112

Viborg Kommune - Beredskabsafdelingen
Tlf. 87 87 87 87

3. Evakuer alle personer på anlægget

Samt alle personer ved porten foran mandskabsbygningen og tjek at bygningen er rømmet, og at døre og vinduer er lukkede

4. Anlæggets eltavler gøres spændingsløse på hovedfordelingstavlen i kedelrummet

CPX1: Forsøgshal med 4 stk. pilotreaktorer (2 x 10 og 2 x 30 m³)
CPX2: Driftsanlæg
CPX3: Efterlæger
LDB2: Mandskabsbygning
LDB1: Forsøgshal

5. Informer receptionen på tlf. 8715 6000

Driftspersonalet sørger for alarmering af naboer i nærmiljøet i henhold til mappen "alarmering af naboer" som findes på driftslederkontoret.

Beredskabsplan på Foulum Biogasanlæg

GASUDSLIP

1. Stands ulykken

Evakuer området i en afstand på 50 meter fra gasudslippet

2. Alarmere

Kontakt en af følgende driftspersonale:

Driftsleder: Mogens Møller
Mobil: 20 76 27 32 eller 86 68 04 30

Driftstekniker: Allan Jensen
Mobil: 20 80 19 97

Driftstekniker: Peter Nielsen
Mobil: 41 12 29 46

Afklar med en af ovenstående driftspersonale om udslippet kræver alarmering af myndighederne.

Alarm
Tlf.: 112

Viborg Kommune - Beredskabsafdelingen
Tlf. 87 87 87 87

3. Stands udslippet og arbejd videre på at reducere skaderne på nærmiljøet

Se nærmere instruktion i mappe 6B, fane 2, side 30, 31 og 32 (mappen står på driftslederkontoret). Placering af ventiler mm. ses på nødplanen til venstre.

4. Informer receptionen på tlf. 8715 6000

Driftspersonalet sørger for alarmering af naboer i nærmiljøet i henhold til mappen "alarmering af naboer" som findes på driftslederkontoret.

Beredskabsplan på Foulum Biogasanlæg

GYLLEUDSLIP

1. Stands ulykken

Luk nærmeste ventiler eller stands pumpen på nærmeste nødstop eller ved pumpens afbryder.
OBS! Man må ikke opholde sig i udstømmende biomasse, da der vil være sundhedsskadelige gasser. Ophold i biomassen må kun ske iført friskluftforsyning og i henhold til øvrige sikkerhedsforskrifter.
(Trailer med friskluftforsyning står i bygning L34). Se desuden mappe 6B, fane 2, side 29 (mappen står på driftslederkontoret)

2. Alarmere

Kontakt en af følgende driftspersonale:

Driftsleder: Mogens Møller
Mobil: 20 76 27 32 eller 86 68 04 30

Driftstekniker: Allan Jensen
Mobil: 20 80 19 97

Driftstekniker: Peter Nielsen
Mobil: 41 12 29 46

Afklar med en af ovenstående driftspersonale om udslippet kræver alarmering af myndighederne.

Alarm
Tlf.: 112

Viborg Kommune - Beredskabsafdelingen
Tlf. 87 87 87 87

3. Stands udslippet og arbejd videre på at reducere skaderne på nærmiljøet

Assistance fra slamsuger og/eller entreprenørmateriel kan fås ved:

Uffe Schmidt – Foulum Markdrift
Mobil: 40 98 74 49

Midtjysk Kloakservice
Tlf.: 86 67 16 33

Tjele Maskinstation v. Bjarne Skydt
Mobil: 40 28 50 71

4. Informer receptionen på tlf. 8715 6000

Driftspersonalet sørger for alarmering af naboer i nærmiljøet i henhold til mappen "alarmering af naboer" som findes på driftslederkontoret.

Contingency plan Foulum biogas plant

FIRE

1. Stop the accident

Types of fire extinguishers are illustrated at the emergency plan to the left.

2. Alarm

Contact one among the following operating personnel:

Manager: Mogens Møller
20 76 27 32 or 86 68 04 30

Technician: Allan Jensen
20 80 19 97

Technician: Peter Nielsen
41 12 29 46

The operating personnel will decide whether the fire brigade must be called.

Emergency service
112

Viborg Kommune
87 87 87 87

3. Evacuate all personnel at the plant

Assemble all personnel at the gate in front of the crew building and make sure that the building is empty and that all doors and windows are closed.

4. Make the circuit breaker panels voltage free at the main distribution board in the boiler room

CPX1: Experiment hall with 4 pilot reactors (2 x 10 og 2 x 30 m³)
CPX2: Biogas facility
CPX3: Post storage
LDB2: Crew building
LDB1: Experiment hall

5. Inform the reception at tel. 8715 6000

The operating personnel is responsible for alarming surrounding neighbours according to the file "Alarming neighbours" which is placed in the Manager's office

Contingency plan Foulum biogas plant

GAS LEAK

1. Stop the accident

Evacuate the area at a distance of 50 metres of the gas leak

2. Alarm

Contact one among the following operating personnel:

Manager: Mogens Møller
20 76 27 32 or 86 68 04 30

Technician: Allan Jensen
20 80 19 97

Technician: Peter Nielsen
41 12 29 46

The operating personnel will decide whether the fire brigade must be called.

Emergency service
112

Viborg Kommune
87 87 87 87

3. Stop the leak and continue to reduce the damage to the immediate environment

See further instructions in file no. 6B, tab no. 2, page 30, 31 and 32 (the file is placed in the Manager's office). Placement of valves is illustrated at the emergency plan to the left.

4. Inform the reception at tel. 8715 6000

The operating personnel is responsible for alarming surrounding neighbours according to the file "Alarming neighbours" which is placed in the Manager's office

Contingency plan Foulum biogas plant

MANURE SPILL

1. Stop the accident

Close the nearest valves or stop the pump by pressing the nearest emergency stop button or the power switch on the pump.

NB! Stays in outflowing biomass are dangerous due to harmful gasses. Stays in the biomass must take place wearing a fresh air supply and according to general safety regulations.

(Fresh air supply is placed in building L34). For further information, see file 6B, tab no. 2, page 29 (the file is placed in the Manager's office)

2. Alarm

Contact one among the following operating personnel:

Manager: Mogens Møller
20 76 27 32 or 86 68 04 30

Technician: Allan Jensen
20 80 19 97

Technician: Peter Nielsen
41 12 29 46

The operating personnel will decide whether the fire brigade must be called.

Emergency service
112

Viborg Kommune
87 87 87 87

3. Stop the spill and continue to reduce the damage to the immediate environment

If assistance from suction vehicles and/or other machinery is needed, please call:

Technician Uffe Schmidt
40 98 74 49

Midtjysk Kloakservice
86 67 16 33

Tjele Maskinstation v. Bjarne Skydt
40 28 50 71

4. Inform the reception at tel. 8715 6000

The operating personnel is responsible for alarming surrounding neighbours according to the file "Alarming neighbours" which is placed in the Manager's office